

TOLERANCE UNLESS OTHERWISE SPECIFIED $.X \pm ... XX \pm$.XX ±

- THESE INSTRUCTIONS ONLY SHOW HOW TO JOIN TWO FIXTURES TOGETHER. SEE MAIN INSTALLATION INSTRUCTIONS (2402861) FOR MOUNTING & WIRING.

SLIDE JOINER INTO ONE FIXTURE END. USE 5/64" DRIVER SECURE JOINER IN PLACE WITH TWO SCREWS PROVIDED. SLIDE NEXT FIXTURE OVER EXPOSED END OF SECURE IN PLACE WITH TWO SCREWS

MAKE WIRE CONNECTIONS. USE 5/64" DRIVER TO SECURE BOTH FIXTURES AT JOINED CONNECTIONS TO CANOPY ASSEMBLY WITH SCREWS

FIXTURE SHOWN VERY SHORT FOR

UCTIONS JOINING					
	SOLD TO:	1		FINISH:	
	ORDER #:			QTY:	
	CLASS:			REV:	SCALE: 1:8
	AUTHOR:			DATE:	
.XXX ±	ANGLES	±	ALL DIMENSIONS ARE IN INCHES UNLESS SPECIFIED OTHERWISE	SHEET #	1 OF 1