

**DESCRIPTION**

The Remote Test Kit (RTK) allows for remote mounting of the test switch and indicator light, and comes in three models:

RTK2PC

For IOTA models with two-piece charger indicator and accessory kits, the RTK2PC consists of three feet of flex, a junction box containing the test switch and charge indicator, and faceplate.

RTKTBTS

For IOTA models with a single-piece test switch and charge indicator, the RTKTBTS consists of three feet of flex, a junction box, and faceplate. The user is expected to mount the existing test switch that came with their emergency ballast/driver to the RTK faceplate.

RTKETS

For IOTA ETS models, the RTKETS consists of three feet of flex, a junction box containing the charge indicator accessory, and faceplate.

When ordering, specify which IOTA models are being equipped with RTK accessories to ensure component compatibility.

INCLUDES

Junction Box

Cover Plate

$\frac{3}{8}$ " flexible conduit with wire (length: 3 ft.)

Test Switch (RTK2PC only) and Charge Indicator (RTK2PC and RTKETS only)

