# **Fresco nLight nIO-X Configuration**

Acuity Brands | One Lithonia Way Conyers, GA 30012 Phone: 800.535.2465 www.acuitycontrols.com © 2014-2016 Acuity Brands Lighting, Inc. All rights reserved. 01/12/16 Part No. 912-00005-002 Rev B

#### REQUIREMENTS

HARDWARE: An nLight nIO-X, Fresco, and external control system using serial commands for control.

FIRMWARE: Fresco Firmware 104.2+

SOFTWARE: nIO-X Encoder/Decoder Application

## RESTRICTIONS

- The channel does not matter when specifying the ON/OFF/DIM/LEVEL action (default to use Channel 1).
- The specific level or dim % command will vary depending on the level or % required, if there is a specific value required, the command string can be generated for it using the nIO-X Encoder/Decoder application. Otherwise, the remaining strings are constant.
- Some status and command / response strings used with the nIO-X are not supported.

### **CONFIGURATION**

Button Configuration	Assign Button #1 to control a Zone, Group, Channel, Scene, Link. The serial commands listed will perform that operation on the target control such as zone 'on' to 100% or going to preset level, or linking/unlinking a room for instance.
	Review the Reference section for serial strings for the Button command string to use for a desired action
Scene Configuration	Assign Scene #1 - #4 to control a Fresco scene. The serial command is always the same, simply change which scene is assigned to the respective scene button (i.e. Scene #1 = Lights On, Scene #2 = Presentation, etc.).
	Review the Reference section for serial strings for each Scene Button command string to use for a desired action.
Tips	Use the nIO X Encoder / Decoder application to generate the strings for dim % values or for the specific level values not pro- vided in the Reference section.
	The Reference section lists the serial strings used for the Scene Buttons and some basic levels for the general Button input.

## REFERENCE

#### **SCENE COMMANDS**

Scene #1 Activate	A5 06 85 01 DF F8
Scene #2 Activate	A5 06 85 02 DF FB
Scene #3 Activate	A5 06 85 03 DF FA
Scene #4 Activate	A5 06 85 04 DF FD

#### **BUTTON COMMANDS**

ON	A5 08 7A 01 01 00 21 F6
OFF	A5 08 7A 01 02 00 22 F6
DIM UP 5%	A5 08 7A 01 03 05 23 F3
DIM DOWN 5%	A5 08 7A 01 04 05 24 F3
LEVEL 0	A5 08 7A 01 05 00 25 F6
LEVEL 100	A5 08 7A 01 05 64 25 92